




1. Set the table.




2. Align the mounting holes for the frame and legs underneath the table and tighten them with screws.



3. Installation completed.



Assembly instructions




DT009WGD240G Installation
The number of people needed for installation: 2

- ① Please read the manual carefully before installing this product. And strictly follow the installation process
- ② Please take good care of this manual for your next installation
- ③ Note: Before installation, screw all the screws to 1/2 of the length of the installation. After all screws are half screwed in, tighten them all together.


Parts list		On a red ribbon are furniture installation accessories		
Serial number	Shape	Name	Quantity required for installation	Spare quantity
A		Hexagonal machine wire (M8*15mm)	4	1
B		Gasket	4	1
C		Wrench 1	1	0
D		Wrench 2	1	0
E		Mechanical adjustable feet can be screwed	0	2
F				
G				

How to solve the problem of gaps and misalignment on the tabletop after the extendable dining table is assembled?


1. If the function panel is found to be unevenly protruding out of the cargo recessed main panel, it can be adjusted by the bottom screws.



2. Find a wrench and loosen the screws in the 4 screw holes in a clockwise direction, just loosen them, you don't have to remove the screws completely.



3. Find the 4 rotatable silver screws above the screw holes, you can adjust the height and level of the function panel with the 4 silver screws, turn the silver screws clockwise to raise the function panel, turn the silver screws counterclockwise to lower the function panel.



4. When the height of the function panel and the main panel are adjusted to the same level, lock the screws in the 4 screw holes in a counterclockwise direction.

