



Assembly Instruction

WF319369 Wf319370 WF319371 WF319372 Wf319374




PARTS




PARTS LIST

A




Seat
1pc

B




Seat
1pc

C




Seat
1pc

D



Left armrest
1pc

E




Back
1pc

F




Back
1pc

G




Back
1pc

H




Right armrest
1pc

M




Sofa leg
16pc

I




Ottoman
1pc

1




Shim
10pc

2




Screw
10pc


3





tool
1pc


PACKAGE





NO	PART	DECS	QTY
A		Seat	1
E		Back	1





NO	PART	DECS	QTY
C		Seat	1
G		Back	1





NO	PART	DECS	QTY
D		Left armrest	1
H		Right armrest	1




NO	PART	DECS	QTY
B		Seat	1
F		Back	1




NO	PART	DECS	QTY
I		Ottoman	1
1		Shim	10
2		Screw	10
M		Sofa leg	16
3		tool	1


Step 1:




Step 2:



Step 3:



Step 4:



Complete

