




 $BD8014DK153/183\ Installation$ The number of people needed for installation: 2


- Please read the manual carefully before installing this product. And strictly follow the installation process
- Please take good care of this manual for your next installation
- 3 Note: Before installation, screw all the screws to 1/2 of the length of the installation. After all screws are half screwed in, tighten them all together.

Parts list On a red ribbon are furniture installation accessories

Serial number	Shape	Name	Quantity required for installation	Spare quantity
A	S)IIIII	Cross recessed screw(M8*20mm)	36	0
В	0	Washer (M8)	36	0
С		Metal foot(H:12cm)	2	0
D		Small angle code	8	0
Е		Rubber pad	8	0
F		Square adjustable leg (H: 24cm)	4	0
G	•	Nut (M8)	4	0
Н		Left corner brace	2	0
Ι		Right corner brace	2	0
J	9	Black rubber foot pad (H:2cm)	2	0
K	411111111P	Self-tapping screw (M5*50mm)	2	0









Installation instruction




 $BD8014DK153/183\ Installation$ The number of people needed for installation: 2


- Please read the manual carefully before installing this product. And strictly follow the installation process
- Please take good care of this manual for your next installation
- 3 Note: Before installation, screw all the screws to 1/2 of the length of the installation. After all screws are half screwed in, tighten them all together.

Parts list On a red ribbon are furniture installation accessories

	This tall at foll accessories				
Serial number	Shape	Name	Quantity required for installation	Spare quantity	
A	S)	Cross recessed screw(M8*20mm)	36	0	
В	0	Washer (M8)	36	0	
С		Metal foot(H:12cm)	2	0	
D		Small angle code	8	0	
Е		Rubber pad	8	0	
F		Square adjustable leg (H: 24cm)	4	0	
G	•	Nut (M8)	4	0	
Н		Left corner brace	2	0	
Ι	<u>;</u>	Right corner brace	2	0	
J	0	Black rubber foot pad (H:2cm)	2	0	
K	4111111111	Self-tapping screw (M5*50mm)	2	0	



4.





Installation instruction




 ${\tt BD8014DK153/183}$ Installation The number of people needed for installation: 2


- Please read the manual carefully before installing this product. And strictly follow the installation process
- Please take good care of this manual for your next installation
- 3 Note: Before installation, screw all the screws to 1/2 of the length of the installation. After all screws are half screwed in, tighten them all together.


Parts list On a red ribbon are furniture installation accessories

This tall at long accesses				1105	
	Serial number	Shape	Name	Quantity required for installation	Spare quantity
	A	SIMM	Cross recessed screw(M8*20mm)	36	0
	В	0	Washer (M8)	36	0
	С		Metal foot(H:12cm)	2	0
	D		Small angle code	8	0
	Е		Rubber pad	8	0
	F		Square adjustable leg (H: 24cm)	4	0
	G	•	Nut (M8)	4	0
	Н		Left corner brace	2	0
	Ι		Right corner brace	2	0
	J	0	Black rubber foot pad (H:2cm)	2	0
	K	<i>₹11111111</i>	Self-tapping screw (M5*50mm)	2	0











 ${\tt BD8014DK153/183}$ Installation The number of people needed for installation: 2

- Please read the manual carefully before installing this product. And strictly follow the installation process
- Please take good care of this manual for your next installation
- 3 Note: Before installation, screw all the screws to 1/2 of the length of the installation. After all screws are half screwed in, tighten them all together.

Parts list On a red ribbon are furniture installation accessories

Serial number	Shape	Name	Quantity required for installation	Spare quantity
A	Simon	Cross recessed screw(M8*20mm)	36	0
В	0	Washer (M8)	36	0
С		Metal foot(H:12cm)	2	0
D		Small angle code	8	0
Е		Rubber pad	8	0
F		Square adjustable leg (H: 24cm)	4	0
G	•	Nut (M8)	4	0
Н		Left corner brace	2	0
Ι		Right corner brace	2	0
J	0	Black rubber foot pad (H:2cm)	2	0
K	<i>₹₩₩₩</i>	Self-tapping screw (M5*50mm)	2	0

